```
# -*- coding: utf-8 -*-
Created on Wed May 18 14:18:39 2017
@author: mullerrs
RUN SCRIPT IN SAME DIRECTORY AS ALL .dat DOCUMENTS OF THE DOM MEASUREMENTS
INCLUDING THE ELECTRONICS .wav FILE OF THE NOISE MEASUREMENT, AND
INCLUDING THE REFERENCE HYDROPHONE .dat MEASUREMENT TO CALIBRATE WITH
I'm sorry I didn't made this automatic yet.
WHEN RUNNING SCRIPT IN COMMANDLINE IT DOES NOT NEED ANY ARGUMENTS (yet)
I also want to implement a -h function and other parsers...
but first things first.
# IMPORT LIBRARIES, FUNCTIONS AND CLASSES
#-----
import sys
import numpy as np
import struct
import os
import math
import scipy.io
import matplotlib.pyplot as plt
from datetime import datetime
from scipy.signal import butter, lfilter
import wavio
from numpy.linalg import norm as Norm
from numpy.fft import fft
# GLOBAL VARIABLES
= 15.25 # frequency of audio source pulses
audioFs
save_txt
         = False # if save_txt == True --> all txt files, are being saved
plotjes
        = False # if plotjes == True --> plots are being made
                                                               <==
save_png
        = False # if save_png == True --> all png files, are being saved
        = False # if show == True --> all plot's are being showed
        = False # if cumm == Trus --> cumpute cummulatives. <== also not always
#-----
# FILTER
def butter_lowpass(cutoff, Fs, order=5):
   nyq = 0.5 * Fs
   normal cutoff = cutoff / nyq
   b, a = butter(order, normal_cutoff, btype='low', analog=False)
   return b, a
def butter_lowpass_filter(data, basename, cutoff, Fs, order=5):
   b, a = butter_lowpass(cutoff, Fs, order=order)
   y = lfilter(b, a, data)
   basename = basename+'_lp%s' %(cutoff/1000)
   return y, basename
```

```
def butter_highpass(cutoff, Fs, order=5):
   nyq = 0.5 * Fs
   normal cutoff = cutoff / nyq
   b, a = butter(order, normal_cutoff, btype='high', analog=False)
   return b, a
def butter highpass filter(data, basename, cutoff, Fs, order=5):
   b, a = butter_highpass(cutoff, Fs, order=order)
   y = lfilter(b, a, data)
   basename = basename+'_hp%s' %(cutoff/1000)
   return y, basename
def butter_bandpass_filter(data, basename, lowcut, highcut, Fs, order=5):
   y = butter_lowpass_filter(data, basename, highcut, Fs, order)[0]
   basename = basename+'_bp%s-%s' %(lowcut/1000, highcut/1000)
   print basename
   return butter highpass filter(y, basename, lowcut, Fs, order)[0], basename
#-----
def Cut(data, samples, Fs, basename):
                                                                           # <=
   MAX = np.max(data)
                                   # Maximum valule in dataset
   treshold = MAX/2.5
   WHERE = np.where(data > treshold) # Samples with value above treshold
   WHERE = np.asarray(WHERE[0]) # Make an array of the tuple
   start_pulse = [WHERE[0]]
                                    # Create an array start_pulse & put
                                    # first sample above MAX/2 init
   # In de komende loop: check voor alle samples boven MAX/2 of ze bij
   # dezelfde pulse horen, of een nieuwe pulse zijn definitie nieuwe pulse is
   # als twee opeenvolgende samples met waarde boven treshold, meer dan Fs/16
   # van elkaar af liggen als een nieuwe pulse gevonden is: voeg deze toe aan
   # start_pulse
   i = 1
   while i < len(WHERE):</pre>
       if WHERE[i] > (start_pulse[-1] + (Fs/(int(audioFs)+1))):
           start pulse.append(WHERE[i])
       i += 1
   N = samples
   cutted_data = np.array([])
   i = 0
   j = 0 # <- to count the removed pulses
   while i < len(start pulse):</pre>
       range I = start pulse[i] - N/2
       cutted_pulse = (data[range_I : range_I+N]) #NB: hij heeft links 1
       # sample meer dan rechts van start_pulse. : is TOT, niet t/m.
       if range I < 0:</pre>
           print 'IndexError occurred - Nothing to worry about: Skipped pulse'
           i += 1
           j += 1
       elif range_I+N > len(data):
           print 'IndexError occurred - Nothing to worry about: Skipped pulse'
           i += 1
           j += 1
       else:
```

```
cutted data = np.concatenate((cutted data, cutted pulse))
         i += 1
   basename = basename + ' pulsecut%s' %samples
   x = float(len(cutted data))/float(N) #how often 1024 samples in cutted data
   if x != len(start_pulse) - j:
      print 'Not all pulses are cutted correctly'
      print '\n Extra info to search for error: \n'
      print 'Expected amount of pulses from data: int of:
                                                    ', len(data)/Fs*auc
      print 'Amount of pulses that should have been plotted =
                                                     , len(start_pulse)
      print 'Amount of pulses cutted =
      print 'Max value
print 'Treshold value
                                                     , MAX
                                                     , MAX/treshold
      print 'Start of the pulses that should have been plotted: \n', start pulse
   ###### PLOT DATA ######
   if ploties == True:
            # unit of file to read in: [raw: Fs], [cut: 1024]
      1 = N
      x = np.linspace(0, 1-1, 1)
      plt.plot(x, cutted_data[0:1], linewidth=1)
      plt.tick_params(axis='both', labelsize=15)
      if '_wavelet_' in basename:
         HYD = 'DOM piezo'
      else:
         HYD = 'reference hydrophone'
      plt.title('\n Single pulse of %s' %HYD, fontsize=24)
plt.suptitle('used: %s'%basename, fontsize=9)
      plt.xlabel('# samples', fontsize=18)
plt.ylabel('amp', fontsize=18)
      plt.tight layout()
      plt.grid()
      plt.grid('on','minor')
      if save png == True:
         plt.savefig(basename+' data one-pulse.png') # data 1wav zoom.png
      if show == True:
         plt.show()
      plt.clf()
   return cutted_data, basename
#-----
# Make time span
def MakeTimeSpan(length, Fs):
   return np.linspace(0, length-1, length)/Fs
# Make frequency span
#-----
def MakeFreqSpan(Fs, NFFT):
   return np.linspace(0, NFFT/2-1, NFFT/2)*float(Fs)/float(NFFT)
# based on Ed's script
#-----
def plot(data, basename, Fs, NFFT):
```

```
length = np.size(data)
   length = len(data)
   time
           = MakeTimeSpan(length, Fs)
   plt.plot(time, data)
   stdev = (np.std(data))
   str = "$\sigma$: %6.4f Pa" % (stdev);
   plt.tick_params(axis='both', labelsize=15)
   plt.title('\n\nTimetrace', fontsize=24)
   plt.suptitle('used: %s\nNFFT: %s\n' %(basename, NFFT) + str, fontsize=9)
   str = "%s -> [%s] " %('amplitude', 'Pa');
   plt.ylabel(str, fontsize=18)
   plt.autoscale(tight = True)
   plt.xlabel('time ->[s]', fontsize=18)
   plt.grid()
   plt.grid('on', 'minor')
   plt.tight_layout()
   if save_png == True:
       plt.savefig(basename+'.png')
   if show == True:
       plt.show()
   plt.clf()
#<==
def MakeSpectrum(Fs, NFFT, data, basename):
   length
              = len(data)
   PSD
              = np.zeros((NFFT/2, 1), dtype=float)
   freq
              = MakeFreqSpan(Fs, NFFT)
   Segment
            = int(length/NFFT)
   if 'sweep' in basename:
            = np.ones(NFFT)
       basename = basename+' wnd rect'
       print '
               rectangular window used'
   else:
             = np.hanning(NFFT)
       basename = basename+'_wnd_hann'
       print ' hanning window used'
              = Norm(wnd)**2
   double2single
   for span in range(0, Segment):
       Bg
                          = span*NFFT
       end
                          = Bg+NFFT
                          = wnd*data[Bg:end]
       уw
                          = fft(yw, NFFT)
       a
       ac
                          = np.conj(a)
                          = np.abs(a*ac)
       xxa
                        += double2single*pxx[0:NFFT/2]
       PSD[:, 0]
   PSD[:, 0] /= (float(Segment)*NFFT*norm)
                                                                              #<==
   basename = basename+ '_spectrum'
   return PSD[:, 0], basename
def PlotSpectrum(Fs, NFFT, data, basename):
   PSD
            = data
   if cumm == True:
```

```
if "10-60kHz" in basename:
           FcumBegin
                      = 10e3 - 5e3
           FcumEnd
                      = 60e3 + 5e3
       elif "50 80kHz" in basename:
           FcumBegin
                      = 50e3 - 5e3
                      = 80e3 + 5e3
           FcumEnd
       elif "Sw50to80kHz" in basename:
           FcumBegin = 50e3 - 5e3
           FcumEnd
                      = 80e3 + 5e3
       elif "DOM_40_ruis" in basename:
           FcumBegin = 30e3 - 5e3
                      = 30e3 + 5e3
           FcumEnd
       elif "2kHz" in basename:
           FcumBegin
                      = 2e3 - 5e3
           FcumEnd
                      = 2e3 + 5e3
       elif "_10kHz" in basename:
   #
            FcumBegin = 10e3 - 5e3
   #
                      = 10e3 + 5e3
            FcumEnd
                      = 3500
           FcumBegin
           FcumEnd
                      = 22500
       elif " 20kHz" in basename:
           FcumBegin
                      = 20e3 - 5e3
           FcumEnd
                      = 20e3 + 5e3
       elif "_30kHz" in basename:
           FcumBegin
                      = 30e3 - 5e3
                      = 30e3 + 5e3
           FcumEnd
       elif " 40kHz" in basename:
                      = 40e3 - 5e3
           FcumBegin
                      = 40e3 + 5e3
           FcumEnd
       elif "_50kHz" in basename:
           FcumBegin = 50e3 - 5e3
                      = 50e3 + 5e3
           FcumEnd
       elif " 60kHz" in basename:
           FcumBegin
                      = 60e3 - 5e3
           FcumEnd
                      = 60e3 + 5e3
       else:
           FcumBegin
                      = 3500
           FcumEnd
                      = Fs/2
       dF
                = float(Fs)/float(NFFT) # amount of freq per bin
       idxB
                = int(FcumBegin/dF)
                                         # bin to start cumsum
                                         # bin to stop cumsum
                = int(FcumEnd/dF)
       cummulative = PSD[idxB:idxE].cumsum();
       std = 10*np.log10(cummulative[-1]); #According to Parseval
   else:
       std = ''
   freq = MakeFreqSpan(Fs, NFFT)
Plot sqrt(PSD), dus met Pa op y-as
sqrt std = np.sqrt(cummulative[-1])
    plt.plot(freq, np.sqrt(abs(PSD)), zorder = 1, linewidth=1) # PSD in dB re amp^2
    #plot cummulatives
    plt.plot(freq[idxB:idxE], abs(cummulative), linewidth=1)
    plt.plot(freq[idxE:idxB-1:-1], abs(PSD[idxE:idxB-1:-1].cumsum()), linewidth=1)
    plt.tick_params(axis='both', labelsize=15)
    str = "$\sigma$ = %6.4f Pa" % (sqrt_std)
    plt.title('\n\nPowerspectrum', fontsize=24)
    plt.suptitle('used: %s\nNFFT: %s\n %s' %(basename, NFFT, str), fontsize=9)
```

#

#

```
plt.ylabel("ampl [Pa] ", fontsize=18)
    plt.autoscale(tight = True)
#
    plt.grid()
    plt.grid('on', 'minor')
#
#
    plt.xlabel('Frequency [Hz]', fontsize=18)
#
    plt.tight layout()
#
    if save png == True:
       plt.savefig(basename+'.png')
#
#
    if show == True:
#
       plt.show()
#
    plt.clf()
Plot 10*log10(PSD), dus dB re Pa op y-as
plt.plot(freq, 10.*np.log10(abs(PSD)), linewidth=1) # PSD in dB re amp^2
   #plot cummulatives
   if cumm == True:
       plt.plot(freq[idxB:idxE],10.*np.log10(abs(cummulative)), linewidth=1)
       plt.plot(freq[idxE:idxB-1:-1], 10.*np.log10(abs(PSD[idxE:idxB-1:-1].cumsum())
   plt.tick params(axis='both', labelsize=15)
   if cumm == True:
       str = "$\sigma$ = %6.4f dB re Pa" % (std)
   else:
       str = ''
   plt.title('\n\nPowerspectrum', fontsize=24)
   plt.suptitle('used: %s\nNFFT: %s\n %s' %(basename, NFFT, str), fontsize=9)
   plt.ylabel("dB re Pa", fontsize=18)
   #plt.autoscale('y', tight = True)
   plt.grid()
   plt.grid('on', 'minor')
   plt.xlabel('Frequency [Hz]', fontsize=18)
   plt.xlim(3000, 88000)
   plt.tight layout()
   if save png == True:
       plt.savefig(basename+' dBrePa.png')
   if show == True:
       plt.show()
   plt.clf()
Plot 10*log10(PSD), dus dB re microPa op y-as
if cumm == True:
       std = 10*np.log10(cummulative[-1]/(1e-6)**2);
   plt.plot(freq, 20*np.log10(np.sqrt(abs(PSD))/1e-6), linewidth=1) # dB re $\mu$Pc
   #plot cummulatives
   if cumm == True:
       plt.plot(freq[idxB:idxE],10.*np.log10(abs(cummulative)/(1e-6)**2), linewidth
       plt.plot(freq[idxE:idxB-1:-1], 10.*np.log10(abs(PSD[idxE:idxB-1:-1].cumsum())
   plt.tick params(axis='both', labelsize=15)
   if cumm == True:
       str = "$\sigma$ = %6.4f dB re Pa" % (std)
   else:
   plt.title('\n\nPowerspectrum', fontsize=24)
   plt.suptitle('used: %s\nNFFT: %s\n %s' %(basename, NFFT, str), fontsize=9)
   plt.ylabel("dB re $\mu$Pa", fontsize=18)
   #plt.autoscale('y', tight = True)
```

```
plt.grid()
   plt.grid('on', 'minor')
   plt.xlabel('Frequency [Hz]', fontsize=18)
   plt.xlim(3000, 88000)
   plt.tight_layout()
   if save png == True:
       plt.savefig(basename+' dBremuPa.png')
   if show == True:
       plt.show()
   plt.clf()
   return
#-----
# PSD Ed - for calibration
#-----
def Spectrum(Fs, NFFT, data, basename):
   length
             = len(data)
   PSD
             = np.zeros((NFFT/2, 1), dtype=float)
   freq
             = MakeFreqSpan(Fs, NFFT)
   Segment
            = int(length/NFFT)
   wnd
             = np.hanning(NFFT)
             = Norm(wnd)**2
   norm
   double2single
                 = 2.0
   for span in range(0, Segment):
                        = span*NFFT
       Bg
       end
                        = Bg+NFFT
                        = wnd*data[Bg:end]
       уw
                        = fft(yw, NFFT)
       a
       ac
                        = np.conj(a)
       рхх
                        = np.abs(a*ac)
       PSD[:, 0]
                        += double2single*pxx[0:NFFT/2]
   PSD[:, 0] /= (float(Segment)*NFFT*norm)
   if plotjes == True:
       plt.plot(freq, PSD[:,0], linewidth=1)
       plt.tick_params(axis='both', labelsize=15)
       plt.title('\nPowerspectrum', fontsize=24)
       plt.suptitle('used: %s\nNFFT: %s'%(basename, NFFT), fontsize=9)
       plt.xlabel('Frequency [Hz]', fontsize=18)
       plt.ylabel('amp$^{2}$', fontsize=18)
       plt.tight_layout()
       plt.grid()
       plt.grid('on','minor')
       if save png == True:
           plt.savefig(basename+'_amp2_calibration.png')
       if show == True:
           plt.show()
       plt.clf()
       plt.plot(freq, np.sqrt(PSD[:,0]), linewidth=1)
       plt.tick_params(axis='both', labelsize=15)
       plt.title('\nPowerspectrum', fontsize=24)
       plt.suptitle('used: %s\nNFFT: %s'%(basename, NFFT), fontsize=9)
       plt.xlabel('Frequency [Hz]', fontsize=18)
       plt.ylabel('amp', fontsize=18)
       plt.tight_layout()
```

```
plt.grid()
       plt.grid('on','minor')
       if save_png == True:
           plt.savefig(basename+'_amp_calibration.png')
       if show == True:
           plt.show()
       plt.clf()
       plt.plot(freq, 20*np.log10(np.sqrt(PSD[:,0])), linewidth=1)
       plt.tick_params(axis='both', labelsize=15)
       plt.title('\nPowerspectrum', fontsize=24)
       plt.suptitle('used: %s\nNFFT: %s'%(basename, NFFT), fontsize=9)
       plt.xlabel('Frequency [Hz]', fontsize=18)
       plt.ylabel('dB re amp', fontsize=18)
       plt.tight_layout()
       plt.grid()
       plt.grid('on','minor')
       if save png == True:
           plt.savefig(basename+' dBreamp calibration.png')
       if show == True:
           plt.show()
       plt.clf()
       plt.plot(freq, 20*np.log10(np.sqrt(PSD[:,0])/(1e-6)), linewidth=1)
       plt.tick_params(axis='both', labelsize=15)
plt.title('\nPowerspectrum', fontsize=24)
       plt.suptitle('used: %s\nNFFT: %s'%(basename, NFFT), fontsize=9)
       plt.xlabel('Frequency [Hz]', fontsize=18)
       plt.ylabel('dB re $\mu$amp', fontsize=18)
       plt.tight_layout()
       plt.grid()
       plt.grid('on','minor')
       if save png == True:
           plt.savefig(basename+' dBremuamp calibration.png')
       if show == True:
           plt.show()
       plt.clf()
   basename = basename + '_spectrum'
   return freq, PSD[:,0], basename
#-----
# GET RATIO ELECTRONICS
                                                                           <==
def Elec ratio(wav file, cal freq, NFFT, lowcut, highcut):
   basename = os.path.splitext(os.path.basename(wav file))[0]
   print('- Electronics of the piezo is being examined using:\n %s' %basename)
   # get properties of the file
   data
                      = wav file
   wavo
                      = wavio.read(data) # returns data.shape, dtype, rate
                                         # and sampwitdt (sampwidth == 3
                                         # <-> 24 bits WAV)
                                        # this can be saved as a .dat file
   data
                      = wavo.data[:,0]
   Fs
                     = wavo.rate
                     = wavo.data.shape[0]
   length
   NFFT
                      = NFFT
```

```
# filter
   data = butter_bandpass_filter(data, basename, lowcut, highcut, Fs, order=5)[0]
   # Make - PSD - amp^2
   freq, PSD, basename = Spectrum(Fs, NFFT, data, basename)
   # Normalize
   sqrt PSD = np.sqrt(PSD)
   PSD10kHz = sqrt_PSD[NFFT*cal_freq/Fs] # check: wat is de waarde bij cal_freq?
   ratios = sqrt_PSD/PSD10kHz
   basename = basename + '_normalized'
   # save
   if save txt == True:
       np.savetxt('20170419 6 white noise 0.9Vrms RATIO nomalized.dat', ratios)
   # plot ratios
   if plotjes == True:
       plt.plot(freq, ratios, linewidth=1)
       plt.tick params(axis='both', labelsize=15)
       plt.title('\n\nNormalized ratio electronics', fontsize=24)
       plt.suptitle('Freq at calibration freq %skHz equals one' %int(cal_freq/1000.
       plt.xlabel('Frequency [Hz]', fontsize=18)
       plt.ylabel('amp', fontsize=18) # only /$\sqrt(Hz)$ if PDS so NFFT = Fs
       plt.ylim(0, 10)
       plt.grid()
       plt.grid('on','minor')
       plt.tight_layout()
       if save_png == True:
           plt.savefig(basename+' amp calibration.png')
       if show == True:
           plt.show()
       plt.clf()
   # plot ratios on dB scale
   if plotjes == True:
       plt.plot(freq, 20*np.log10(ratios), linewidth=1)
       plt.tick_params(axis='both', labelsize=15)
       plt.title('\n\nNormalized ratio electronics')
       plt.suptitle('Freq at calibration freq %skHz equals one' %int(cal_freq/1000.
       plt.xlabel('Frequency [Hz]', fontsize=18)
       plt.ylabel('dB re amp',fontsize=18) # only sqrt(Hz) if PDS so NFFT = Fs
       plt.ylim(-20, 20)
       plt.grid()
       plt.grid('on','minor')
       plt.tight layout()
       if save png == True:
           plt.savefig(basename+'_dBreamp_calibration.png')
       if show == True:
           plt.show()
       plt.clf()
   return freq, ratios
#-----
# CORRECTION FOR DISTANCE
#-----
```

def distance_correction(config):

```
print('- Determine distance correction\n'
            based on 1 over distance squared relation')
   if config == 1:
       RD = 0.52
                     #[m]
       SD = 0.97
                     #[m]
       SR = SD - RD
                     #[m]
       print 'distance_correction has not been determined for this config'
   elif config == 2:
       RD = 0.52
                     #[m]
       SD = 0.97
                     #[m]
       SR = SD - RD
                     #[m]
   elif config == 3:
       RD = 0.52
                     #[m]
       SD = 0.97
                     #[m]
       SR = SD - RD
                     #[m]
       print 'distance correction has not been determined for this config'
   elif config == 4:
       RD = 0.52
                     #[m]
       SD = 0.94
                     #[m]
       SR = SD - RD
                     #[m]
       print 'distance_correction has not been determined for this config'
   elif config == 5:
       RD = 0.52
                     #[m]
       SD = 0.94
                     #[m]
       SR = SD - RD
                     #[m]
       print 'distance_correction has not been determined for this config'
   elif config == 6:
       RD = 0.5
                     #[m]
       SD = 1.
                     #[m]
       SR = SD - RD
                     #[m]
       print 'distance correction has not been determined for this config'
   elif congif ==7:
       RD = 1.5
                     #[m]
       SD = 2.
                     #[m]
       SR = SD - RD
                     #[m]
   distance_correction = SR**2/SD**2
   return distance_correction
#-----
# CALIBRATION VALUE
def IJk value(hyd data, basename, Fs, NFFT, FcumBegin, FcumEnd):
   Fs = Fs
   if Fs == int(25e6/128):
       print '- Determine calibration value of the DOM using:\n %s' %basename
   elif Fs == 2e5:
       print '- Determine calibration value of the REF using:\n %s' %basename
   # PSD in amp^2
   freq, PSD, basename = Spectrum(Fs, NFFT, hyd_data, basename)
   # Because noise measurement only shows peaks of electronics
   # we do not subtract noise.
```

```
# determine cumsum
   dF
            = float(Fs)/float(NFFT)
                                      # amount of freq per bin
   idxB
            = int(FcumBegin/dF)
                                      # bin to start cumsum
   idxE
            = int(FcumEnd/dF)
                                      # bin to stop cumsum
   cummulative = PSD[idxB:idxE].cumsum();
   std = 10*np.log10(cummulative[-1]); #According to Parseval
   sqrt std = np.sqrt(cummulative[-1])
   print '
             sigma = %6.4f dB re amp, or sigma = %6.4f amp' %(std, sqrt_std)
   if plotjes == True:
       plt.plot(freq, np.sqrt(abs(PSD)), zorder = 1, linewidth=1) # PSD in dB re an
       #plot cummulatives
       plt.plot(freq[idxB:idxE], abs(cummulative), linewidth=1)
       plt.plot(freq[idxE:idxB-1:-1], abs(PSD[idxE:idxB-1:-1].cumsum()), linewidth=
       plt.tick_params(axis='both', labelsize=15)
       str = "$\sigma$ = %6.4f amp" % (sqrt std)
       plt.title('\n\nPowerspectrum', fontsize=24)
       plt.suptitle('used: %s\nNFFT: %s\n %s' %(basename, NFFT, str), fontsize=9)
       plt.ylabel("amp ", fontsize=18)
       plt.autoscale(tight = True)
       plt.grid()
       plt.grid('on', 'minor')
       plt.xlabel('Frequency [Hz]', fontsize=18)
       plt.tight layout()
       if save_png == True:
           plt.savefig(basename+'.png')
       if show == True:
           plt.show()
       plt.clf()
       plt.plot(freq, 10.*np.log10(abs(PSD)), zorder = 1, linewidth=1) # PSD in dB
       #plot cummulatives
       plt.plot(freq[idxB:idxE],10.*np.log10(abs(cummulative)), linewidth=1)
       plt.plot(freq[idxE:idxB-1:-1], 10.*np.log10(abs(PSD[idxE:idxB-1:-1].cumsum())
       plt.tick_params(axis='both', labelsize=15)
       str = "$\sigma$ = %6.4f dB re amp" % (std)
       plt.title('\n\nPowerspectrum', fontsize=24)
       plt.suptitle('used: %s\nNFFT: %s\n %s' %(basename, NFFT, str), fontsize=9)
       plt.ylabel("dB re amp", fontsize=18)
       plt.autoscale(tight = True)
       plt.grid()
       plt.grid('on', 'minor')
       plt.xlabel('Frequency [Hz]', fontsize=18)
       plt.tight layout()
       if save png == True:
           plt.savefig(basename+' dB.png')
       if show == True:
           plt.show()
       plt.clf()
   calibration value = sqrt std
   return calibration value
# PREPARE THE FILES USED FOR CALIBRATIONVALUES
```

```
def get cut filt IJkfile(file ijkHYD, Fs, lowcut, highcut, NFFT):
   print '- Cut and filter data of:\n %s' %file ijkHYD
   Fs = Fs
   ijkHYD = np.genfromtxt(file ijkHYD)
   basename = os.path.splitext(os.path.basename(file ijkHYD))[0]
   ijkHYD, basename = butter_bandpass_filter(ijkHYD, basename, lowcut, highcut, Fs,
   ijkHYD, basename = Cut(ijkHYD, NFFT, Fs, basename)
   return ijkHYD, basename
#-----
# CALIBRATE
#-----
def CalibrationArray(file_electronics, file_ijkDOM, file_ijkREF, lowcut, highcut, ca
                    .wav file
                               .dat file
                                            .dat file
   print('\nGOING TO MAKE CALIBRATION ARRAY')
   elec_freq, elec_ratio = Elec_ratio(file_electronics, cal_freq, NFFT, lowcut, hig
   dimension less, since it's a ratio
   ijkDOM, basenameDOM = get_cut_filt_IJkfile(file_ijkDOM, Fs_DOM, lowcut, highcut,
   ijkREF, basenameREF = get_cut_filt_IJkfile(file_ijkREF, Fs_REF, lowcut, highcut,
   DOM_val_X = IJk_value(ijkDOM, basenameDOM, int(25e6/128), NFFT, cal_min, cal_max
   REF_val_Pa = IJk_value(ijkREF, basenameREF, int(2e5), NFFT, cal_min, cal_max) #
   sensitivity value = (DOM val X / REF val Pa) # in [X]/[Pa]
   dist_cor = distance_correction(config = 2)
   calibration value = sensitivity value / dist cor
   print '- Used values used for calibration:'
          Sensitivity value (DOM/REF) = %s' %sensitivity_value
   print '
           Distance correction value = %s' %dist cor
           Resulting calibration value = %s' %calibration value
   return elec_freq, elec_ratio, calibration_value
def main():
   #start timer
   startTime = datetime.now()
   # input values for calubration:
                = 'wav10kHz'
                                                                     # Sp
   cal_type
   file electronics= '20170419 6 white noise 0.9Vrms.WAV'
                                                           # .wav
                                                                     # el
   file ijkDOM = '20170310_config2_DOM_6_v1_wavelet_10kHz.dat' # .dat
                                                                     # fi
                = 'Time Conf2Domwavelet10kHzv1.dat'
                                                                    # fi
   file ijkREF
                                                           # .dat
   lowcut
                = 1000
                                                           # [Hz]
                                                                     # Lc
                = 80000
   highcut
                                                           # [Hz]
                                                                    # ur
                = 10000
   cal_freq
                                                           # [Hz]
                                                                    # WE
   samples_to_cut = 1024
                                                           # [samp]
                                                                    # 50
   NFFT
                = samples_to_cut # do NOT change this!
                                                           # [samp]
                                                                   # 50
   Fs_DOM
                = int(25e6/128)
                                                           # [samp/s] # sc
```

```
= int(2e5)
    Fs REF
                                                                      # [samp/s] # sc
    cal min
                   = 3500
                                                                      # [Hz] # Lc
                   = 22500
                                                                      # [Hz]
    cal_max
                                                                                # ur
    #get electronics ratio, and calibration value
    elec freq, elec ratio, calibration value = CalibrationArray(file electronics, fi
    #due to different Fs, elec_freq is slightly different from freq --> levert 1.6%
    print '\nNOW CALIBRATE THE DATA:'
    for fn in os.listdir('.'):
        #DOM
        if ".dat" in fn:
            Fs = Fs DOM
#
        if "Time Conf2Domwavelet10kHzv1.dat" in fn:
#
            Fs = Fs REF
        #SOURCE
        if "Wavelet 10kHz 5Vpp.dat" in fn:
#
                                                                                  #san
#
            Fs = 1e6
            # get file --> Less datapoints for tone and sweep
            print '- %s' %fn
            basename = os.path.splitext(os.path.basename(fn))[0]
            if 'toon' in fn:
                data = np.genfromtxt(fn, max_rows = Fs/2)
            if 'sweep' in fn:
                data = np.genfromtxt(fn, max_rows = Fs/2)
            else:
                data = np.genfromtxt(fn)
            # filter file. Cutting possible, but not needed
            data, basename = butter bandpass filter(data, basename, lowcut, highcut,
            #data, basename = Cut(data, NFFT, Fs, basename)
            #CALIBRATE DATA FILE (timetrace)
            data = data / calibration_value
            basename = 'c_%s_' %(cal_type) + basename
print ' save: %s.dat'%basename
            # save file
            if save txt == True:
                np.savetxt(basename+'.dat', data)
            try:
                plot(data, basename, Fs, NFFT)
            except OverflowError:
                print 'OverflowError - Allocated too many blocks'
                print 'Skip plot of timetrace'
            PSD, basename = MakeSpectrum(Fs, NFFT, data, basename)
                                                                                 #<==
            #CALIBRATE DATA FILE (timetrace)
            PSD ELcor = (np.sqrt(PSD) / elec ratio)**2
            # save file
            if save_txt == True:
                np.savetxt(basename+'PSD.dat', PSD)
                np.savetxt(basename+'PSD_ELcor.dat', PSD_ELcor)
            print ' save: %sPSD.dat'%basename
```